

# DSSE

## PRODUCT MANUAL



## HYDRA BEIGE BED BB13

### **Entry-Level Luxury with a Golden Touch**

The Hydra beauty couch blends everyday functionality with a luxurious aesthetic, making it the perfect entry-level bed for brow and lash professionals. It features three adjustable sections to support a range of treatments. Its standout champagne gold base adds a touch of glamour, while the fixed 70cm height ensures comfortable access and ergonomic working conditions.

Designed to impress, built to perform.

## Introduction

This manual is intended solely as a reference for the operation of this specific model. DSSE assumes no responsibility or liability for any consequences resulting from its use for other purposes. All information contained in this manual is protected by copyright and may not be copied, reproduced, or translated, in whole or in part, without the prior written consent of our company.

### Safety Instructions

- Always disconnect the power supply before changing electrical components or performing maintenance and cleaning on the equipment.
- The plug must be connected to a properly installed and grounded outlet to prevent the risk of fire or electric shock.
- Do not stand on the equipment.
- Keep children away from the equipment; place it out of their reach. Always adjust the backrest to its highest position when leaving the equipment unattended.
- Do not place the equipment in damp or wet areas such as bathrooms to avoid electric shock or malfunction. The remote control should also be kept away from water.
- Avoid using the equipment in environments where painting, coating, or oxygen provision is taking place.
- Unless supervised or instructed by qualified personnel, people with physical disabilities, sensory disorders, mental impairments, lack of experience or common sense, and children are not permitted to use the equipment.
- If the plug is damaged, contact your distributor, service center, or a qualified professional for repair.
- Ensure there are no objects within the equipment's movement range during operation.
- All maintenance must be performed by trained professionals only.

## Precautions

- The equipment should be operated by experienced personnel familiar with its structure, performance, and instructions.
- Read this manual carefully before installation, operation, and adjustment. Keep it for future reference.
- Do not use for single-side or single-point loading.
- Follow safety operation rules. Do not overload. Ensure all safety equipment is reliable and address any hazards immediately.
- Regularly tighten bolts and nuts to avoid failure due to loosening or vibration.
- Do not disassemble parts without proper authorization.
- If faults occur or abnormal noises are heard, stop usage immediately and have the equipment inspected.
- Only resume use after proper troubleshooting.
- This bed uses a three-wire power cord and must be plugged into a grounded outlet.
- Observe all warning labels on the product.
- Press and hold the control button when adjusting the bed height until the desired position is reached.
- Motor operation time: 2 minutes ON, 18 minutes OFF to prevent overheating).
- Clean dust and stains using a neutral cleaning agent after each treatment.
- Keep hands, feet, and head clear of moving parts during adjustments.

## ENTRY-LEVEL CARE, GOLD STANDARD

The Hydra beauty couch is a versatile, expertly crafted bed trusted by beauty professionals and tattoo artists alike. Ideal for brow and lash services, facials, and a wide range of treatments, it provides exceptional support and lasting comfort. Its elegant champagne gold frame and plush upholstery deliver a modern, polished aesthetic—making it a standout feature in any salon or studio setting.

### Adjustable Backrest (0° - 55°)

Manually adjustable by hand lever, the backrest allows you to customize the seating angle for optimal comfort and support.

### Removable Armrests

Adjustable and detachable armrests provide added comfort and flexibility.

### Secure Support

Sturdy base with support pins, resting on four black castors for stability and mobility.



### Large Face Hole

Enjoy extra comfort with a large breathing hole

### Ergonomic Comfort

Upholstered in PU vinyl with memory foam, it offers enhanced comfort and long-lasting durability.

### Adjustable Legrest (0°-45°)

Manual hand lever adjustment for maximum comfort and support.

## Product Specifications

Length:	<b>184cm</b>
Width without/with Arms:	<b>60/80cm</b>
Height:	<b>70cm</b>
Backrest Adjustment Angle:	<b>Up to 55°</b>
Legrest Adjustment Angle:	<b>Up to 45°</b>
Net Weight:	<b>32 kg</b>
Gross Weight:	<b>36 kg</b>
Max. Load Capacity:	<b>150 kg (seating position)</b>



## Style, Simplicity, and Salon-Ready Comfort

The Hydra beauty couch offers a streamlined solution for professionals seeking both functionality and style. Designed with three adjustable sections, it supports a variety of treatment positions while maintaining optimal comfort for both client and therapist. Upholstered in premium PU vinyl, the surface is smooth, durable, and easy to maintain. A fixed working height of 70cm promotes ergonomic efficiency, and the champagne gold base provides a clean, modern aesthetic suitable for any clinical or salon environment. Ideal as an entry-level option for brow and lash treatments.



### Leg and Backrest Adjustment

Both sections manually adjusted by hand lever



## Upholstery Care Guide

As a professional esthetician, investing in a high-quality electric facial bed can significantly enhance the comfort and effectiveness of your treatments. To maintain that level of performance and ensure long-term reliability, regular maintenance and proper care are essential. Like any professional equipment, your facial bed requires routine attention to stay in optimal working condition—ensuring safety, smooth functionality, and a consistently elevated experience for your clients.

### General Care Tips

Maintain a stable temperature:

- Cold can lead to vinyl cracking
- Heat may cause permanent stretching

Keep out of direct sunlight for long periods to prevent fading and damage. Regular housekeeping helps preserve comfort and appearance.



### Cleaning Instructions

Clean frequently to remove body oils that can harden vinyl

Use a colorfast cloth dampened with lukewarm water and mild, alkaline-free soap

Avoid soaking the material

Wipe off any soap with fresh water and a clean cloth

Dry thoroughly with a soft, dry cloth

For tougher grime, gently scrub with a soft brush



## Avoid Using These Products

- Hot or boiling water
- Alcohol or hydrocarbon-based cleaners
- Acetone
- Bleach or harsh detergents
- Furniture polish
- Abrasive powders, pastes, or steel wool
- Silicone or petroleum-based products
- Solvent-based or abrasive cleaning agents

## Routine Inspection

Perform periodic checks on:

- Hinges • Fasteners • Structural components

Ensure your chair remains safe, stable, and fully functional.

Do not dispose of old or defective appliances with household waste. Please use designated public collection points for proper disposal. This manual is for reference only. Specifications may change without prior notice.

### WARRANTY PERIOD

STANDARD **12 MONTH** WARRANTY APPLIES TO THIS PRODUCT.

For more information about our warranty, please refer to our website.

DSSE

Australia: [www.dsse.com.au](http://www.dsse.com.au)  
United Kingdom: [www.dssebeauty.co.uk](http://www.dssebeauty.co.uk)  
Europe: [www.dssebeauty.eu](http://www.dssebeauty.eu)