

DSSE

PRODUCT MANUAL



MIA HYRAULIC BED BB04

Streamlined Comfort with Manual Versatility

Designed for professionals across beauty, wellness, and tattoo industries, the Mia Hydraulic offers a perfect balance of functionality, comfort, and stability. This 3-section treatment couch features a heavy-duty hydraulic pump for smooth height adjustment, while the backrest and leg sections are manually operated for easy positioning.

Introduction

This manual is intended solely as a reference for the operation of this specific model. DSSE assumes no responsibility or liability for any consequences resulting from its use for other purposes. All information contained in this manual is protected by copyright and may not be copied, reproduced, or translated, in whole or in part, without the prior written consent of our company.

Safety Instructions

- Always disconnect the power supply before changing electrical components or performing maintenance and cleaning on the equipment.
- The plug must be connected to a properly installed and grounded outlet to prevent the risk of fire or electric shock.
- Do not stand on the equipment.
- Keep children away from the equipment; place it out of their reach. Always adjust the backrest to its highest position when leaving the equipment unattended.
- Do not place the equipment in damp or wet areas such as bathrooms to avoid electric shock or malfunction. The remote control should also be kept away from water.
- Avoid using the equipment in environments where painting, coating, or oxygen provision is taking place.
- Unless supervised or instructed by qualified personnel, people with physical disabilities, sensory disorders, mental impairments, lack of experience or common sense, and children are not permitted to use the equipment.
- If the plug is damaged, contact your distributor, service center, or a qualified professional for repair.
- Ensure there are no objects within the equipment's movement range during operation.
- All maintenance must be performed by trained professionals only.

Precautions

- The equipment should be operated by experienced personnel familiar with its structure, performance, and instructions.
- Read this manual carefully before installation, operation, and adjustment. Keep it for future reference.
- Do not use for single-side or single-point loading.
- Follow safety operation rules. Do not overload. Ensure all safety equipment is reliable and address any hazards immediately.
- Regularly tighten bolts and nuts to avoid failure due to loosening or vibration.
- Do not disassemble parts without proper authorization.
- If faults occur or abnormal noises are heard, stop usage immediately and have the equipment inspected.
- Only resume use after proper troubleshooting.
- This bed uses a three-wire power cord and must be plugged into a grounded outlet.
- Observe all warning labels on the product.
- Press and hold the control button when adjusting the bed height until the desired position is reached.
- Motor operation time: 2 minutes ON, 18 minutes OFF to prevent overheating).
- Clean dust and stains using a neutral cleaning agent after each treatment.
- Keep hands, feet, and head clear of moving parts during adjustments.

STYLE, STRENGTH, SEAMLESS SUPPORT

Experience elevated comfort with the Mia Hydraulic Beauty Bed—a beautifully crafted treatment bed known for its versatility and trusted by both beauty professionals and tattoo artists. Ideal for brow and lash services, facials, massages, and more, it offers exceptional support across a wide range of treatments. With its sleek base and plush upholstery, the Mia adds a modern, professional finish to any salon or studio space.

Adjustable Backrest (0° - 55°)

Manually adjustable by hand lever, the backrest allows you to customize the seating angle for optimal comfort and support.

Height Adjustment (68 - 92 cm)

Adjustable height by hydraulic foot pump located at rear of base

Elegance from the Ground Up

A slimline, sculpted base that lets you get closer to your client for precision and comfort in every treatment.

Wide Insert Pillow

Enjoy extra comfort with a wider pillow insert

Ergonomic Comfort

Channeled curves contour to the body, offering superior comfort and support throughout treatments.

Adjustable Legrest (0°-70°)

Manual lever adjustment for maximum comfort and support.



Product Specifications

Length:	186cm
Width without/with Arms:	62/82cm
Height Range:	68-92cm
Backrest Adjustment Angle:	Up to 55°
Legrest Adjustment Angle:	Up to 70°
Net Weight:	83 kg
Gross Weight:	98 kg
Max. Load Capacity:	180 kg (seating position)



Simple Form, Powerful Function

The Mia Hydraulic Beauty Bed blends elegant design with robust functionality, offering a perfect balance of comfort, durability, and versatility. Built to meet the demands of modern beauty professionals, it features smooth hydraulic height adjustment and a stable, supportive structure—making it ideal for salons, tattoo parlours and treatment rooms focused on both style and performance.

How To Use

Follow these instructions to operate the electric beauty bed safely and effectively.



Height Adjustment

Gently step on the foot lever to adjust the height up and down



Leg and Backrest Adjustment

Both sections manually adjusted by hand lever

Upholstery Care Guide

As a professional esthetician, investing in a high-quality electric facial bed can significantly enhance the comfort and effectiveness of your treatments. To maintain that level of performance and ensure long-term reliability, regular maintenance and proper care are essential. Like any professional equipment, your facial bed requires routine attention to stay in optimal working condition—ensuring safety, smooth functionality, and a consistently elevated experience for your clients.

General Care Tips

Maintain a stable temperature:

- Cold can lead to vinyl cracking
- Heat may cause permanent stretching

Keep out of direct sunlight for long periods to prevent fading and damage. Regular housekeeping helps preserve comfort and appearance.



Cleaning Instructions

Clean frequently to remove body oils that can harden vinyl

Use a colorfast cloth dampened with lukewarm water and mild, alkaline-free soap

Avoid soaking the material

Wipe off any soap with fresh water and a clean cloth

Dry thoroughly with a soft, dry cloth

For tougher grime, gently scrub with a soft brush



Avoid Using These Products

- Hot or boiling water
- Alcohol or hydrocarbon-based cleaners
- Acetone
- Bleach or harsh detergents
- Furniture polish
- Abrasive powders, pastes, or steel wool
- Silicone or petroleum-based products
- Solvent-based or abrasive cleaning agents

Routine Inspection

Perform periodic checks on:

- Hinges • Fasteners • Structural components

Ensure your chair remains safe, stable, and fully functional.

Do not dispose of old or defective appliances with household waste. Please use designated public collection points for proper disposal. This manual is for reference only. Specifications may change without prior notice.